

4. ASSEUBLE ACAIN
5. START THE PULLA AND MAKE SURE WATER IS FLOWING.
THROUG CONDENSER

6. COLLECT THE HYDROSOR IN A CLUP OR CONTAINTER

- THE HYDROSOZ CAN BE USED IN A SPRAY BOTTLE
- 7. FILL THE IL BOILING FLASK /3 FULL OF WATER
- 8. START THE BURNER RECATIVE SLOW UNTIL WATER BOILS THE YOU CAN GO FULL POWER.
- 9. THE STEAM WILL GO THROTECTH THE PLANT
 NATERIAL AND YOU WILL START SEEING OIC
 ON TOP OF THE OIL SEPERATOR.
- 10, AFTER ABOUT 20 MINTETES YOU SHOULD HAVE
 YOUR OIL YOU CAN TRY ANOTHER 10 MINCETES,
 TO SEE IF ANY MORE OIL COLLECTS, IF NOT,
 STOP THE BURNER.
- 11. DIS ASSEMBLE, THROW OUT THE OLD BIOMASS.
- 12. IF YOU DO A NEW ACANT MATERIAL, RINSE
 ALL WITH HOT SOAPY WATER UNTIL YOU DONT
 SMELL THE OLD OIL.
- 13. DONT STRESS OF AND ENJOY IT

SARTU_

PLEASE ASK IF ANY THING 15 UNCLEAR.

DISCONNECT THE SILICONE TUBING HELE WHEN CLEANING. THE METAL HOSE MAKES DISCONNECTIVE EASY.